

AXGT

Replacement for any damaged or lost sensor. For use with models listed below *

Specifications

Dimensions: (Inside) .52" x .52"
(Outside) 2.52" x 2.00" x 1.75"

***Only For**

Use With: RIBXJA, RIBXJF, RIBXLCJA, RIBXLCJF, RIBXLSJA, RIBXLSJF

Purpose: Can replace any damaged or lost sensor.
For use with the models listed above.

Replacement

