

AXR

Replacement for any damaged or lost sensor. For use with models listed below *

Replacement



Specifications

Dimensions: (Inside Diameter) .75"
(Outside Diameter) 2.28"

***Only For**

Use With: RIBMXRA, RIBMXRF

Purpose: Can replace any damaged or lost sensor.
For use with the models listed above.