

RIBMNA1D0



Functional
Devices, Inc.
B1087 · 393096A


Input Voltage
24Vac/dc

Input Current
90mA Max

Feedback Contact
2A Max @ 24Vac/dc


Override Impedance Limitations

0-5Vdc, 200 Ω Min
0-10Vdc, 400 Ω Min
0-15Vdc, 1k Ω Min
0-20mAdc, 500 Ω Max



Legend for Selecting Output for Jumpers

- Top 2 pins covered by jumper
- Bottom 2 pins covered by jumper
- Only 1 pin covered by jumper



Notes:

- Set the jumpers according to your input signal (Analog signal from the controller.) Example: When controlling a damper with 0-10 Vdc, the jumpers need to be in position for the 0-10 Vdc override range. If the LED range does not match your analog scale, ensure the jumpers are set for the proper range.
- Feedback contact closed when switch is in Manual position, open when switch is in Auto position.

RIBMNA1D0



Functional
Devices, Inc.
B1087 · 393096A


Input Voltage
24Vac/dc

Input Current
90mA Max

Feedback Contact
2A Max @ 24Vac/dc


Override Impedance Limitations

0-5Vdc, 200 Ω Min
0-10Vdc, 400 Ω Min
0-15Vdc, 1k Ω Min
0-20mAdc, 500 Ω Max



Legend for Selecting Output for Jumpers

- Top 2 pins covered by jumper
- Bottom 2 pins covered by jumper
- Only 1 pin covered by jumper



Notes:

- Set the jumpers according to your input signal (Analog signal from the controller.) Example: When controlling a damper with 0-10 Vdc, the jumpers need to be in position for the 0-10 Vdc override range. If the LED range does not match your analog scale, ensure the jumpers are set for the proper range.
- Feedback contact closed when switch is in Manual position, open when switch is in Auto position.

RIBMNA1D0



Functional
Devices, Inc.
B1087 · 393096A


Input Voltage
24Vac/dc

Input Current
90mA Max

Feedback Contact
2A Max @ 24Vac/dc


Override Impedance Limitations

0-5Vdc, 200 Ω Min
0-10Vdc, 400 Ω Min
0-15Vdc, 1k Ω Min
0-20mAdc, 500 Ω Max



Legend for Selecting Output for Jumpers

- Top 2 pins covered by jumper
- Bottom 2 pins covered by jumper
- Only 1 pin covered by jumper



Notes:

- Set the jumpers according to your input signal (Analog signal from the controller.) Example: When controlling a damper with 0-10 Vdc, the jumpers need to be in position for the 0-10 Vdc override range. If the LED range does not match your analog scale, ensure the jumpers are set for the proper range.
- Feedback contact closed when switch is in Manual position, open when switch is in Auto position.