

REPLACEMENT

AXGT

Split Core Remote with Terminals, Replacement for Any Damaged or Lost Sensor, for Use with Models Listed on Data Sheet



SPECIFICATIONS

Dimensions: (Inside) .52" x .52"
(Outside) 2.52" x 2.00" x 1.75"

***Only For Only for Use With:** RIBXJA, RIBXJF, RIBXLCJA, RIBXLCJF, RIBXLSJA, RIBXLSJF
Can replace any damaged or lost sensor.

Purpose: For use with the models listed above.

Origin: Made of US and non-US parts

